

GENI Instrument and Measurement System (GIMS)


Paul Barford, Mike Blodgett, Charles
Thomas, Joel Sommers

UW Madison
Colgate University

GIMS

High Speed Packet Capture

- AJAX-enabled GUI for control.
- Traffic capture hardware/software (PC with DAG card).
- MySQL Database.
- Aggregate Manager to coordinate.
- Data storage (local and third-party vendors).
- XML/RPC used for control commands.



Functionality:

- Create new experiment.
- Configure capture device (for a given experiment).
- Start/Stop capture.
- Get experiment settings.
- Monitor experiment status or get experiment results.

GIMS - GENI Instrument and Measurement Systems

User authentication not obtained.

Welcome to GIMS!

Action to perform:

Create New Experiment

Capture Device Name:

msn:pc-i5-46-v

Experiment ID:

EXP_C035608D

Submit

GIMS - GENI Instrument and Measurement Systems

User authentication not obtained.

Setup GIMS Capture Parameters

Received data from GIMS Aggregate Manager:

Aggregate manager received command GetDeviceCapabilities.

Result:

Received device capabilities: location='msn', device='pc-i5-46-v'

Site: msn

Device: pc-i5-46-v

Experiment ID: EXP_E691DFF7

Storage Type:

- local
- s3
- ssh

Storage Options:

/home/net/GIMS/cthomas

Filtering:

- VLAN Num
- Host Addr.
- Dest Addr.
- Host Port
- Dest Port
- Protocol

Sampling:

param:

Aggregation:

Anonymization:

► Add Libpcap String

► Add User Notes

Submit

Reset

GIMS - GENI Instrument and Measurement Systems

User authentication not obtained.

GIMS: Get Experiment Settings

Site: msn
Device: localhost
Experiment ID: EXP_700CA6DD

Received data from GIMS Aggregate Manager:

Aggregate manager received command GetExperimentSettings.

Received response from database:

```
<StorageSpec>
storagetype => local
<storageparams>
local_storage_dir => /home/net/foo
</storageparams>
</StorageSpec>
<CaptureSpec>
filterexpr => src host 144.42.12.23 and dst host 144.42.12.1 and src port 80
device => localhost
</CaptureSpec>
<MetaDataSpec>
UserText => These are some user notes. Make note of them.
</MetaDataSpec>
MethodName => ConfigureExperiment
SiteLocation => msn
DeviceName => localhost
<AggregationSpec>
aggtype => none
</AggregationSpec>
VLAN => 123
<AnonSpec>
anontype => none
</AnonSpec>
ExperimentID => EXP 700CA6DD
```

[Return to Start](#)

GIMS - GENI Instrument and Measurement Systems

User authentication not obtained.

GIMS Control Panel

Site: msn

Site: msn

Device: localhost

Experiment ID: EXP_700CA6DD

Received data from GIMS Aggregate Manager:

```
Aggregate manager received command StartExperiment.
```

Received response from device:

```
Starting capture!
```

Select an Action:

[Start Capture](#)

[Stop Capture](#)

[Return to Start](#)

Current State of Project:

- Working to replace original capture control software with next generation software.
- Expansion of AJAX functionality to allow a smoother user experience.
- Moving toward integration of GENI authentication mechanisms.
- System benchmarking.
- Public availability.

For more information:

- Charles Thomas <cthomas@wisc.edu>
- Paul Barford <pb@cs.wisc.edu>
- Mike Blodgett <mblodget@cs.wisc.edu>>
- Joel Sommers <jsommers@colgate.edu>